

RIEGL Airborne Laserscanner Systeme für die effiziente Kartierung großflächiger Gebiete: Technik, Anwendungen und Ausblick

> Peter Rieger Manager ALS Business Division





- » *RIEGL* Airborne Laserscanner und Systeme
- » VQ-780II-S und VQ-1560II-S
- » Systemtechnik Scanmechanismen
- » Effizienz Flächenleistung
- » RiPROCESS 1.9

## novation in 3D

**ALS Lineup** 





#### www.riegl.com

#### Copyright RIEGL LMS © 2021 - All rights reserved.

#### Innovation in 3D

## novation in 3D



## VQ-78011-S

- The *RIEGL* VQ-780II ist a state-of-the-art waveform processing LIDAR
- up to 2 million laser pulses per second, yielding up to
  1.33 million pulses/measurements per second on the ground
- data acquisition at a wide range of avg. point densities:
  2 pts/m<sup>2</sup> up to more than 70 pts/m<sup>2</sup> (@ 80kn, 400m AGL)
- Multiple-Time-Around (MTA) processing of up to
  36 pulses simultaneously in the air (2500m AGL @ target reflectivity 60%)
- online waveform processing and/or full waveform recording and smart waveform recording
- excellent multiple target detection capability
- external inertial measurement unit and GNSS receiver

## **NEW RIEGL VQ-780 II-S**

with increased laser power for ultra-wide area mapping measurement range up to 4,800 m (target reflectivity  $\ge 20\%$ )







## Polygon mirror wheel



## nnovation in 3D



## The VQ-1560 series



## **Dual Channel Waveform Processing Airborne LiDAR Systems**

#### fully integrated with IMU/GNSS and cameras

- online waveform processing and smart and full waveform recording
- up to 2.66 million measurements/sec on the ground

### RIEGL VQ-1560 II

**two infrared laser channels** for a high maximum range and a wide selection of point densities with an optimum distribution of the measurements on the ground

- for large scale, high altitude, complex environment mapping
- measurement range up to 4,500 m (target reflectivity ≥ 20%)

### RIEGL VQ-1560 II-S

with increased laser power for ultra-wide area mapping

 measurement range up to 4,800 m (target reflectivity ≥ 20%)

### RIEGL VQ-1560-DW

enhanced target characterization by simultaneous measurements at green and infrared laser wavelengths

## mmovation in 3D

### The new VQ-1560II-S

### **Dual Channel Laser Scanner:**

- NEW: up to 1.4x extended measurement range
- extremely fast: 2 x 2 MHz
- unique dual channel design
- forward-nadir-backward "Crossfire" looking capability
- high point density and best point spacing
- Full Waveform and Online Waveform Processing
- gapless acquisition from all altitudes

## **Compact Laser Scanner System:**

- with integrated high-grade IMU/GNSS system
- with integrated 150 MPix camera
- with optional 150 MPix NIR camera or thermal IR camera
- for optional use with gyro-stabilized mounts (GSM 4000)









## Dual channel polygon mirror wheel



## Innovation in 3D



## The VQ-880G-II

## Green channel

- high measurement rate (up to 700 kHz)
- circular scan pattern (up to 80 lines per second)
- online waveform processing
- waveform storage capability
- IR channel
  - high measurement rate (up to 279 kHz)
  - nearly linear scan pattern (up to 100 lps)
- Cameras
  - 2 PhaseOne cameras (RBG and NIR)
  - up to 100 MPixel CMOS without FMC or up to 80 MPixel CCD with FMC







## ALS: Palmer Scanner – rotating glass wedge



novation in 3D



**RIEGL VQ-880-GII** 

### **RIEGL linear vs. oscillating and circular scan pattern**



- Linear scan lines
- "matrix scan"

- tilted straight scan lines
- optimum interleaving independent of acquisition parameters
- interleaving zig-zag or sinusoidal scans
- prone to "unfavorable" phase conditions



- circular scan pattern
- unfavorable point distribution

ovation in 3D



Point Distribution: Polygon Mirror Wheel

point pattern centre





Point Distribution: Circular scan pattern



www.riegl.com

Point Distribution: Circular scan pattern



Innovation in 3D

COM Copyright RIEGL LMS © 2021 – All rights reserved.

www.riegl.com





### Example 1: VQ-780II – linear vs. circular scan pattern





#### point pattern edge

www.riegl.com Copyright RIEGL



### Example 3: VQ-1560II – linear vs. circular scan pattern







#### **Point Density**



#### Innovation in 3D



#### **Point Density**



#### Innovation in 3D

## ovation in 3D

## **RiPARAMETER**

#### **RIPARAMETER**

SETTINGS 🔀 INPUT/OUTPUT Scanner Type **Result Qualifier** SUCCESS N 8-4 MTA Zone 24 1776m MTA Zone 25 1850m Scanner Settings Hight Height– 1654m AGL ٠ MTA Zone 26 1924m VO-1560II-S 2 x 2000 HOVE NOHD- 152m 100 58.52° 2 x 222 Angular Step Width: 0.01000 **Project Requirements** 58.5 Wide Area Mapping -Flight Parameters Uniform Point Pattern: 5427 1654 pts/m<sup>2</sup> 2 x 10.00 Avg. 5427 1654 0.0 ÷ 140 259 71.9 Terrain Scan Pattern @ Min. Terrain Altitude 0 ÷ ft 0 0 m 4 ENOHD= 1061m Swath Width: 1853 1853 0 ‡ ft 0 ‡ m Flight Height Constraints 0 0 0 ‡ ft 0 ¢ m 0.314 0 🗘 m Point Distance: 0 0.289 0.318 0.385 Observe ENOHD • 2 x 8.27 pts/m 2 x 10.00 2 x 11.0 Surface / Target / Atmosphere MTA Details 20.0 \$ % 75.0 Terrain Altitude= Om Swath Width= 1853m Terrain Variation= Topography . Overview, Zoom to section of Zoom to section of min. point density ÷. 23 26 subsampled by a factor of 214 max. point density Productivity 40km Very Clear ٠ 480 Aircraft Cessna T206H STATIONAIR 4 2 x 86.4 🗘 kn Min. Speed: 80 148 🗘 km/h 2 x 178 🗘 kn Max. Speed: 140 259 🗘 km/h Laser Safety Information Zoom to section of area, point density 26000 ‡ ft 7925 \$ m 9% 152 1061 64% Auxiliary Limits 2019 97% 448736 Scanrate-Range-Prod. 68%



🕀 RIEGL

## nnovation in 3D

## 

## **Crossfire Scan Pattern**

- 2-channel laser optical design
- Single rotating mirror
- 2x matrix scan pattern
- "Interleaved" design provides homogenous point distribution across entire FOV (58 deg.)
- Increased vertical density with off-nadir and nadir view angles









## **CROSSFIRE Simulations of Coverage**

#### **Small House MODEL**

Size: 6 x 6 m Height: 3.5 m Roof angle: 30 deg



#### **Building w/ Inner Court MODEL** Size outside: 12 x 10 m Size inside: 6 x 4 m Height: 10.5 m









































movation in 3D





movation in 3D





nnovation in 3D





movation in 3D





## **RiPROCESS 1.9**



- 64-bit modules allows accessing huge memories conveniently
- faster processing reduced data handover
- less and smaller data files less data volume

**KINEMATIC DATA PROCESSING** 







RiPROCESS 1.9 performance improvement (wrt. 1.8.7)

- processing speed (raw data to georefenced point cloud, ALS data, no waveforms)
  x 1.8 faster
- data storage size (*RIEGL* VQ-780 II data, partially with waveforms)
  50% to 75% file size reduction
- speed of scan data adjustment (boresight alignment)
  x 3 faster
- speed of colorizing (georeferenced point clouds, lots of images, e.g., LadyBug)
  x 3 to x 4 faster
- speed of exporting (colorized point clouds, in LAS 1.2)
  x 6 to x 10 faster

## Innovation in 3D



## Licensing scheme in RiPROCESS 1.9

serial number licenses tied to RIEGL LiDAR device:

- require RiPROCESS 1.9 (or any of the modules, e.g., RiUNITE)
- may require updating of the V-Line LiDAR instrument's firmware (for reliable signature of serial number)
- licenses can be installed and utilized concurrently on any number of workstations / laptops via *RIEGL's* License Center
- enables an **infinite number of instances** running concurrently on every workstation
- no dongles required
- especially suited for mass data processing in the cloud





# Thank you for your kind attention!



Copyright RIEGL Laser Measurement Systems GmbH © 2020 – All rights reserved. Use of this presentation other than for personal purposes requires RIEGL's written consent. The presentation is compiled with care. However, errors cannot be fully excluded and alternations might be necessary.